TRANSFER INSTRUCTIONS PRINTCO.

	•	+
300°F	10 sec. 5 sec.	7 firm pressure

1 Design will be printed as a mirror image with white ink on surface.



2 Place garment on heat press and direct to film transfer onto garment with image (right reading) facing up.

- **3** Press with firm pressure at 300°F for 10 seconds.
- **4** Hot peel the film unless the film is glossy then remove from press and warm peel
- 5 Peel film from garment



If the transfer does not want to release from the film, let the film cool and/or rub with a cloth for 10 seconds to cool

6 Place garment on heat press, cover with parchment paper or Teflon and press for 5



